



This is a digital copy of a book that was preserved for generations on library shelves before it was carefully scanned by Google as part of a project to make the world's books discoverable online.

It has survived long enough for the copyright to expire and the book to enter the public domain. A public domain book is one that was never subject to copyright or whose legal copyright term has expired. Whether a book is in the public domain may vary country to country. Public domain books are our gateways to the past, representing a wealth of history, culture and knowledge that's often difficult to discover.

Marks, notations and other marginalia present in the original volume will appear in this file - a reminder of this book's long journey from the publisher to a library and finally to you.

Usage guidelines

Google is proud to partner with libraries to digitize public domain materials and make them widely accessible. Public domain books belong to the public and we are merely their custodians. Nevertheless, this work is expensive, so in order to keep providing this resource, we have taken steps to prevent abuse by commercial parties, including placing technical restrictions on automated querying.

We also ask that you:

- + *Make non-commercial use of the files* We designed Google Book Search for use by individuals, and we request that you use these files for personal, non-commercial purposes.
- + *Refrain from automated querying* Do not send automated queries of any sort to Google's system: If you are conducting research on machine translation, optical character recognition or other areas where access to a large amount of text is helpful, please contact us. We encourage the use of public domain materials for these purposes and may be able to help.
- + *Maintain attribution* The Google "watermark" you see on each file is essential for informing people about this project and helping them find additional materials through Google Book Search. Please do not remove it.
- + *Keep it legal* Whatever your use, remember that you are responsible for ensuring that what you are doing is legal. Do not assume that just because we believe a book is in the public domain for users in the United States, that the work is also in the public domain for users in other countries. Whether a book is still in copyright varies from country to country, and we can't offer guidance on whether any specific use of any specific book is allowed. Please do not assume that a book's appearance in Google Book Search means it can be used in any manner anywhere in the world. Copyright infringement liability can be quite severe.

About Google Book Search

Google's mission is to organize the world's information and to make it universally accessible and useful. Google Book Search helps readers discover the world's books while helping authors and publishers reach new audiences. You can search through the full text of this book on the web at <http://books.google.com/>

PRECIS OF LECTURES
ON
MILITARY CARRIAGES, ETC.,
FOR THE USE OF THE
GENTLEMEN CADETS OF 1st CLASS,
ROYAL MILITARY ACADEMY.

BY
BT.-LIEUT.-COLONEL W. KEMMIS, R.A.

WOOLWICH:
PRINTED AND PUBLISHED BY F. J. CATTERMOLÉ, ARTILLERY PLACE.
1882.





00044254P



PRECIS OF LECTURES
ON
MILITARY CARRIAGES, ETC.,
FOR THE USE OF THE
GENTLEMEN CADETS OF 1st CLASS,
ROYAL MILITARY ACADEMY.
BY
BT.-LIEUT.-COLONEL W. KEMMIS, R.A.

WOOLWICH:
PRINTED AND PUBLISHED BY F. J. CATTERMOLE, ARTILLERY PLACE.
1882.

2316. d. 14



PRECIS OF LECTURES

ON

MILITARY CARRIAGES, ETC.

MATERIALS.

Timber:—

- Growth of.
- Classes of.
- Chief English woods, their characteristics and uses.
- Chief Foreign woods, their characteristics and uses.
- Seasoning: principle and method of, evils of not seasoning wood.
- Conversion: meaning of
- Drying: object of.

Wood-Work, Manufacture:

- Cross cutting.*
- Planking.*
- Marking out.*
- Cutting out.*
- Shaping.*
- Buffing.*
- Sawing boards to thickness.*
- Sawing boards to length.*
- Dovetailing.*
- Tenoning and mortising.*
- Rabbling and grooving.*
- Joining boards.*
- Olamping.*
- Ammunition boxes, complete.*
- Axle boxes, complete.*
- Frames of wood wagons.*

Wrought-iron :—

Sections of bar used.
 Difference between “ re-manufactured ” and “ bar ” iron.
 Test for bar iron.
 Test for plate iron.
 Average strength of bar and plate.

Cast-iron :—

General purposes for which used and reasons for such use.

“ Malleable ” cast-iron and steel articles.

How produced.
 Properties.
 Class of articles made “ malleable.”

Steel :—

Descriptions used.
 Peculiarities of each description and purposes to which put.
 Nature of steel used for carriage brackets and axles.

“ Metal ” :—

To what the term “ metal ” is applied.
 General purposes for which “ metal ” is used.
 Ingredients and effect of each.
 Phosphor bronze : composition, marking, and application.

Leather :—

Methods of tanning.
 Test for quality.
 Test for cleanness.
 Effect of harness paste, soaps, &c.

Rope :—

Descriptions.
 Size : how measured.
 Rule for strength, when new.

Paint :—

Description of paint and colour used : for ironwork and for
 woodwork.

THE WHEEL.

Principal parts of.

Classification of wheels, with example of each class.

Patterns of wheels and differences in construction between them.

Principles of construction :—

Object of a wheel.

Resistance to rolling ; to what due and how measured.

The nave :—

Wood used for the “stock,” and reason of its selection.

Proper position of the spokes in the nave.

Qualities desirable in the metal used for the pipe-box.

Metals used for the pipe-box and their relative advantages.

Internal form of the pipe-box.

Qualities desirable in the metal used for flanges.

Relative advantages of the “wood” and “metal” nave.

The spokes :—

Wood used, and reason of its selection.

The number of spokes and the section of each.

“Dish” of a wheel: what it is, its object, disadvantage, remedy for the disadvantage and evil in the remedy, measurement of dish, its amount in field and siege wheels.

“Strut:” what it is, its object, measurement, its amount in field and siege wheels.

The felloes :—

Wood used and reasons for its selection.

The number of felloes : how governed.

The radius to which felloes are cut, and reason.

“Bevelling:” meaning and reason for.

The tire :—

Purposes which the tire serves.

Material used.

Width of tire : advantages and disadvantages of width, amount in field, siege and transport wheels.

Comparison of the “streak” and the “ring” tire.

Height of wheels :—

Advantages and disadvantages of height.

Amount in field, siege and transport wheels.

Weight of Wheels :—**Considerations which rule the weight.****The weight of the field, siege and transport wheels.****Manufacture of the N.P. Wheel :—***Spokes.**Felloes.**Wheel put together.**Tire put on.**Turning for nave.**Drilling for tire bolts.**Turning the felloes on the inside.**Putting in the nave.**Finishing.***Manufacture of a ring tire :—***Measuring the bar approximately.**Bending.**Welding.**Measuring exactly.**Bevelling.***Manufacture of a metal nave :—***Making the mould for the pipe-box.**Making the mould for the flanges.**Forming the core.**Washing moulds and cores.**Casting.**Trimming.**Turning.***Manufacture of a cast iron pipe-box :—***The mould.**The core.***Manufacture of side bars for saddle trees :—***Sawing out the bars.**Turning.*

THE AXLE TREE.

Materials used for axles.

Parts of an axle.

Classes of axles.

Patterns of axles and differences between them.

The reasons for the axle "arm" being conical, and of small diameter.

The usual sections of the "body."

"Hollow": definition and object of.

"Lead": definition and object of.

"Set": definition of.

Manufacture of a wrought-iron axle:—

Formation of a "bloom" for half an axletree.

Forging the body.

Forming the arm.

Forming the shoulder.

Bending up the end of the body, &c.

Turning.

Welding the halves of the axle together.

Guaging.

Manufacture of a steel axle:—

Steel ingot for complete axle, forged at centre.

Re-heated as required and body, shoulder, and arms forged in succession.

Turning.

LINCH PINS & WASHERS.

Classes.

Material.

Forms of washers.

FIELD ARTILLERY CARRIAGES.

Principles of construction :—

Conditions of employment of Field Artillery Carriages and their consequent essential qualities.

The mode of draught : relative advantages of shaft and pole draught.

Tractive force :—

Weights which a horse can draw under different circumstances.

Teams employed and the weights they can draw.

Distribution of the weight behind the team.

Connection between the fore and hind carriage :—

Horizontally.

Vertically.

Stability :—

The “upsetting” angle of a carriage.

Manner in which the angle is measured.

Upon what the amount of the angle depends.

The amount of the angle for field carriages.

Strength :—

The effect of a load on the centre of a beam supported at each end.

The neutral axis.

The resistance of the beam to the strain of the load.

The reason that iron is often more suitable for construction of carriages than wood.

Simplicity :—

The reasons it is to be desired.

Transport :—

The disadvantage entailed in construction from the necessity of having sea transport to provide for.

The gun carriage :—

The force of discharge : where and how received.

Effects of the vertical component of the force of discharge.

The manner in which the strains due to the vertical component are met.

Effects of the horizontal component of the force of discharge.

The manner in which the strains due to the horizontal component are met.

The blow on the elevating gear : how produced.
 Strain from the gun being rifled.
 Height of the axis of the trunnion-holes : how governed.
 Position of the trunnion holes : how ruled.
 Length of the trail : considerations respecting.

The Limber :—

Position of the limber hook.
 Point from which the draught should be taken.

Track :—

Definition and amount of.

Tonnage :—

Method of taking.

9-pr. R.M.L. Gun Carriage :—

Parts.

Construction of the brackets.

Position and object of the transoms.

Object of the "collar" bolts.

Object and methods of steeling the trail eye.

Object of the steel plate under the point of the trail.

Construction of the "box-girder" axle and bed.

Object of the tensile stays.

The means of elevating.

The means of traversing.

Desirability of means to check recoil and the objection to checking it more than necessary.

The so-called "elastic" carriages.

The axle boxes.

The field limber :—

General construction.

The shafts.

The ammunition boxes.

The ammunition wagon :—

General construction.

The remaining wagons of a Field Battery :—

Purpose of each.

13-pr. R.M.L. Carriages :—

Peculiarities of.

Manufacture of an iron field gun carriage :—

Parts of the frame.
Forging the trunnion piece.
Welding the frame.
Cutting out the plate.
Drilling the rivet holes in frame and plate.
Rivetted frame and plate together.
Erecting the carriage.
Machine operations :—
 Boring.
 Slotting.
 Planing.
 Shaping.

Manufacture of an iron field limber :—

Forging the splinter bar.
Erecting.

SIEGE ARTILLERY CARRIAGES.

Conditions of employment different to Field.

Carriages for guns for "direct" fire :—

The ordinary "overbank" carriage: for example, that for the 40-pr. R.M.L. gun.
 Differences in construction between the 40-pr. "siege" and the 9-pr. "field" carriage.
 The means of elevating.
 The means of traversing.
 The means of checking the recoil.
 Differences between the "siege" and "field" limber.
 The "disappearing" overbank carriage: for example, the "Moncrief hydro-pneumatic."

Carriages for howitzers for "indirect" fire: for example, that for the 6·3 inch R.M.L. howitzer :—

Peculiarities.
 Means of checking the recoil.

Carriages for howitzers for "high angle" fire: for example, that for the 6·3 inch R.M.L. howitzer and that for the 7-pr. R.M.L. gun :—

The 6·3 inch "bed" :—
 General construction.
 Object in placing it upon rollers.
 Means of traversing.

Means of checking the recoil.

Means of elevating.

Means of transporting.

The 7-pr. "bed" :—

General construction.

Means of elevating.

Its platform.

"Ground" platforms :—

The "double-decked."

Clerk's.

Those for rifled howitzers.

MOUNTAIN ARTILLERY CARRIAGES.

The load for a mule.

Method of checking recoil.

Ammunition boxes.

General arrangement of the 7-pr. equipment for transport.

TRANSPORT CARRIAGES.

Reason that a limbered wagon is not suitable for Transport Service.

Difficulties in the construction of a wagon for Transport Service.

The height of the wheels : how ruled.

Relative advantages of carts and wagons ; reasons the former cannot altogether take the place of the latter.

Position of the centre of gravity of the load in a cart.

Advantages and disadvantages of springs.

ENGINEER CARRIAGES.

Peculiar in the use of springs.

General arrangements for transporting the pontoon equipment.

General arrangements for transporting the telegraph equipment.

REGIMENTAL CARRIAGES.

Means of transporting small-arm ammunition.

GARRISON CARRIAGES.

The different classes of garrison carriages.

Wrought-iron "sliding," "double plate" carriages:—

The different descriptions.

The 7-inch R.M.L. carriage, as an example of the R.C.D. construction:—

General construction.

Means of running up.

The "capstan-head" elevating gear: general arrangement and disadvantage.

Object of the metal lining in the trunnion holes.

Object of "clip plates."

The "Elswick" compressor: description, action and disadvantages.

Object of the white line on the carriage.

The "worm-wheel" elevating gear:—

Description.

Advantage.

Captain Scott's principles of construction.

10-inch R.M.L. carriage, Mark II, as illustrating those principles.

12·5-inch R.M.L. carriage, Mark I.:—

Method of throwing the carriage upon its rollers.

Elevating gear: general arrangement.

"Nipping" gear: general arrangement.

12·5-inch R.M.L. carriage, Mark II. :—

Peculiarity in the arrangement of the “hydraulic buffer.”

10-inch R.M.L. “small port” carriage :—

Object of such carriage.

General arrangement of the lifts and peculiarity of the elevating gear.

Wrought-iron “traversing” platforms for double plate carriages :—

Two descriptions of platform.

Pivots :—

What they are, and their respective positions.

Circumstances under which each nature of pivot is employed.

When “actual” and when “imaginary.”

Trucks :—

Their form, size, position and material.

Traversing Gear :—

Reason applied to certain platforms.

Desiderata in such gear.

The different descriptions.

7-inch R.M.L. platform :—

General construction.

Means of traversing and running back.

The hydraulic buffer :—

Description.

Action.

Advantages.

Modifications of.

9-inch R.M.L. platform :—

The nature of the traversing gear.

The trucks to which it is applied.

How arranged to traverse, or run back, as required.

The graduated arc and pointer.

10-inch R.M.L. platform :—

Construction of the sides.

Advantage of a comparatively high platform, such as Mark II. compared to Mark I.

12·5-inch R.M.L. platform, Mark I. :—

The nature of the gear.

12·5 inch R.M.L. platform, Mark II. :—

Peculiarity in the arrangement of the hydraulic buffer.

The disc clutch.

Manufacture of frames for Scott's pattern carriage:—

Making the mould.

Casting.

Graduating elevating arcs.

Manufacture of wrought-iron platforms:—

Bending girder sides.

Stamping out trucks.

Turning trucks.

Planing racers.

Manufacture of bolts, nuts and rivets:—

Forging bolts.

Forming the heads of rivets.

Stamping out nuts.

Cutting screw thread on bolts and nuts.

MONCRIEF CARRIAGES AND PLATFORMS.

Principles of the "counterweight" system.

General arrangement.

Difference between the first and the second pattern.

Object of the "brake" gear.

Means of elevating and laying.

Means of moving the "elevator" by hand.

MACHINES.

The hydraulic jack:—

Single action.

Double action.

NAVAL CARRIAGES.

The "bow" compressor.

Peculiarity in the shape of the bars and plates.

Advantage of.

New pattern elevating gear for 9-inch R.M.L. carriage :—

Method of clamping.

NOTE ON TRACTION.

Resistance to rolling is caused by obstruction of the ground to the onward motion of a wheel: this may be due to—


1. Raised obstacles, as stones in the path of the wheel.
2. The wheel sinking into a rut, or trench, and consequently having to rise out of it again.
3. Inclination of the ground.

The amount of resistance opposed either by a raised, or sunken, obstacle cannot be measured by the height to which the wheel has to be lifted to pass over the former, or get out of the latter, as the mere height gives no indication of the power of the wheel, due to its diameter, for surmounting the obstruction.

The resistance is therefore measured, not by the height the wheel has to be raised, but by substituting for it an equivalent incline, the angle of which depending both upon the height of the obstruction, and upon the radius of the wheel, gives a true measure of the resistance opposed to the motion: further such an angle is convenient for purposes of calculation.

The incline (FGB'), equivalent to an obstruction of given height (FB'), is arrived at, if the wheel is on level ground as in Fig. I, and if on sloping ground as in Fig. II, by drawing a tangent ($B'G$) to the wheel at its point of contact with the obstacle, when about to surmount it, to meet the original ground line (FB).

FIG. I.—*Wheel on level.*



and upon the speed at which he travels : it may generally be taken for duration of labour from 4 to 5 hours, as follows :—

Trotting at speed of about 7 miles an hour, 70lbs.
 " " " 6 " 82lbs.

The relation, mathematically deduced, between the tractive power P and weight behind it, on level ground, is given by the equation $P = \frac{r \cdot W'' \cdot \cos \epsilon \cdot \mu}{R} + (W'' + W') \sin \epsilon$. Where r = radius axle, R = radius wheel, W'' = weight of carriage and load, W' = weight of wheels, ϵ = inclination of traces, μ = co-efficient of friction between wheel and axle. If the carriage is upon ground sloping at an angle with the horizontal = γ , for $\sin \epsilon$ must be substituted $\sin (\epsilon + \gamma)$.

From calculation and experience we find that, corresponding to the above duration of labour and respective rates of motion, the horse may be expected to draw under service conditions :—

In Horse Artillery, about $5\frac{1}{2}$ cwt.
 In Field Artillery " 7 cwt.
 In Transport (without springs), &c., $9\frac{1}{2}$ cwt.

Teams of two abreast only are adapted to field service.

Six horses are the greatest number which can usefully be employed in the field for manoeuvre ; eight may be employed exceptionally, but with loss of useful effect.

The weights which the different teams should draw, under ordinary service conditions, are about as follows :—

Horse Artillery	... team of six	34½ cwt.
Field "	" six	42 "
Field "	" eight	49 "
Field Transport	" four (wagon without springs)	38 "
"	" six	57 "
"	" four (wagon with springs)	54 "

The weight behind a team includes the carriage and its load, and in order that the weight of the latter may be as great as possible, the weight of the former must be a minimum consistent with the requisite strength.

To make the draught as easy as possible, the load must be distributed in the proper proportion over the fore and hind axles ; in the field gun carriage the distribution desired must be modified to meet particular circumstances, thus : there must be carried the gun, the necessary ammunition and stores, entrenching tools for immediate use, and also sufficient men to serve the piece. The quantity of ammunition, stores, and tools, should be enough to render the gun sufficiently independent of its wagon in action : it is usually laid down that the number of rounds with the gun should be from 30 to 40, and of this about four rounds should be at hand in action on the gun carriage : the total number of rounds carried by a battery, that is between the gun carriages and the wagons, should be from 100 to 150 per gun, or sufficient to render the battery tolerably independent of the first reserve of ammunition in an action.

The mode of draught of a carriage may either be "shaft" or "pole;" in the British service the former mode is preferred for field artillery carriages, because there is more control over the carriage for manœuvre, while it is better for crossing bad ground. Pole draught is however the simpler arrangement, and divides the strain more equally between the wheel horses.

NOTE ON 13PR. R.M.L. FIELD CARRIAGES.

The following are the chief points of difference between the carriages of the 13-pr. equipment and that of the 9 or 16-pr.

THE GUN CARRIAGE.—This is constructed of steel, instead of wrought iron, for greater strength.

The wheels have an additional grease chamber, which not only gives greater space for grease, but supplies it at the outer bearing on the axle (the grease having a tendency to run up the arm), while it is arranged to admit of being filled without removal of the wheel from the arm.

The axletree and bed is of the "bow-string" girder form, which is of greater strength than the "box" girder in being of greater depth under the brackets and throwing the strain on discharge in the direction of the length of, rather than across, the axle. The latter is not weakened by many rivet holes, and is readily removable.

The brackets have the plate inside the angle of the frame, which causes greater mutual support between the two, and takes the strain off the rivets.

The trail is short, making an angle of about 30° instead of 23° with the ground, which tends to lighten and at the same time strengthen the trail; it has, however, a tendency (though practically imperceptible) to increase the "jump" by decreasing the resistance to the latter offered by the moment of the weight of the gun and carriage about the point of the trail. Further, it tends to check recoil by increasing the tendency of the trail to dig into the ground.

The tensile stays are comparatively long, to bring the strain thrown upon them, and from them to the brackets, more in the direction of their length; they are readily removable for repair.

The elevating gear is the worm wheel pattern with friction cone.

There are no axle boxes, but simple axle seats on springs; on each bracket are bands for leather cases, in which a round of ammunition can be placed, if desired, from the limber.

THE LIMBER.—Has the bow string girder axle and bed; the axle interchangeable with that of the gun carriage.

It has four futchells instead of three, and carries but two boxes (the fuzes and tubes packed with the remainder of the ammunition), these open to the rear, enabling the ammunition to be readily removed. The boxes contain each 18 rounds.

THE WAGON BODY.—Has also the bow-string girder axle and bed, the axle interchangeable with that of the limber and gun carriage.

The hind boxes open to the rear, but the front at top; their packing is neither identical with each other nor with that of the limber boxes.

They carry 70 rounds, making, with those of the limbers, 142 rounds per subdivision.

NOTE ON THE MONCRIEF HYDRO-PNEUMATIC DISAPPEARING SIEGE GUN CARRIAGE.

THE carriage consists of a body upon a siege axle with siege wheels, the latter 5' 6" in height, an hydraulic cylinder with plunger, two radius bars and elevating gear.

The body of the carriage is in the form of an obtuse-angled triangle, the obtuse angle downwards, the front acute angle attached to the axle and the rear acute angle, forming the point of the trail, resting on the ground.

The cylinder, of metal, is supported on trunnions at the obtuse angle of the body of the carriage: its interior is formed in two compartments connected towards the lower part by two valves: the plunger, or ram, carrying the gun, by its trunnions, in a fork at its upper extremity, works in the central or inner compartment: the trunnions of the gun are also secured in the radius bars which pivot round the axle of the carriage.

The breech of the gun is connected by bars with elevating worm wheel gear on the carriage, and is so arranged that the gun in the loading position is brought horizontal without respect to the elevation it had in the firing position.

For action the carriage is secured to a holdfast in front, plates are placed under the wheels and trail, and the cylinder filled about $\frac{3}{4}$ with water and $\frac{1}{4}$ with compressed air (by means of an air pump, or from an air-holder of metal previously filled by means of an air pump). The exact proportion of air to water and amount of compression of the former has to be properly adjusted.

On discharge, the gun, being in the firing position, forces the ram into the cylinder, the water under the ram being driven to the outer compartment of the cylinder through one of the valves (the "discharge" valve—by which it cannot return) and compressing the air there still further. During this recoil of the gun its trunnions pivot in the radial arms and in the head of the ram, the radial arms round the axle and the cylinder on its trunnions.

To bring the gun from the position of recoil (or loading) to the firing position, the other valve (or "raising" valve, which permits of the water returning from the outer to the inner compartment of the cylinder), is opened by a lever, when the force stored up in the compressed air comes into play, forcing the water back under the ram and raising the latter with the gun. The rise of the gun, by means of the lever handle, is under perfect control, but to prevent it going further than desired, there are check chains.

The chief advantages of the system are as follows :—

The gun is effectually covered except at the moment of firing, and fires over 7' 6" parapet, instead of 5' 6", as in the ordinary overbank carriage.

It is brought from the loading to the firing position without labour.

The recoil is taken up mainly in the carriage, no labour being necessary to run up, and the detachment remaining close to the parapet.

The strain of discharge is usefully absorbed, instead of hurtfully expended on the carriage.

No ground platform proper is required.

The chief disadvantages of the system are, that with small charges sufficient compression of air cannot be obtained to bring the gun back to the firing position, also that a holdfast is required for the carriage: it is however to be noted that a holdfast is equally required with such siege carriages as it has been found necessary to fit with the hydraulic buffer in order to control the recoil.

NOTE ON THE 12.5 INCH R.M.L. CARRIAGE AND PLATFORM. MARK II.

THESE differ from Mark I. in having the hydraulic buffer attached to the bottom of the carriage, instead of to the platform, and recoiling with it and the piston-rod secured to the front transom of the platform instead of to the carriage: by this arrangement on discharge the rod is placed in tension instead of under compression, which description of strain it can better withstand. The front buffer-cap of gun-metal forms the bracket for securing the front of the buffer to the carriage, the rear being attached by means of a wrought-iron band.

The platform is fitted with a disc, instead of a cone-clutch, in the traversing and running-back gear: this consists of two parts, one for traversing (*a*), and the other (*b*) for running back. Each is formed of a series of plates alternately of gun-metal (*c*) and of steel (*d*), the former revolving with the pinion, and the latter with the shaft; when these are pressed together, by the clutch lever, against either of the pinions *a* or *b*, and the shaft is driven by the winch handle; the clutch and pinion revolve with the shaft.






Plate I.



Action of Discharge on Field Line Curvature (15.25.28. 26.10.)

10.10.28 - 1.5



10.10.28

Plate III.






Plate IV.







CYLINDER
of the
Moncrief Hydro-pneumatic Carriage.





The "Bow" Compressor

Plate V'II.

